


PLUTZ 2




- A** Bridle Point. Use 10-15lb Spectra to fly
- B** Sliding Glide Adjuster
- C** Top Stoppers
- D** Canard Adjusters
- E** Sail Standoffs
- F** Permanent Main sail tie

Note:

You do not need to adjust any of the above points with the exception of **A** (Bridle Point) **B** (Sliding Glide Adjuster) and **D** (Canard adjusters).

B is the most active adjustment you will make (see below).


D is factory tuned so you its not really necessary to adjust it. Shortening it gives shorter glides. Also used to tune the kite's straight tracking.



- More pull
- More sensitive
- Less pull
- Less sensitive

Bridle Point Adjustment

Gold marking is the recommended adjustment. Slide it up or down to find your preferred sensitivity. Adjust with 0.5 cm increments.



- Shorter Glide
- Windy Conditions
- Smaller space
- Longer Glide
- Zero Wind
- Bigger space

Sliding Glide Adjuster

Gold marking is the recommended glide adjustment. Slide it up or down to find your favourite glide distance. Adjust with 0.5 cm increments.

Tip:

Pull as a kite until overhead then slack the line to glide!

Start with 50 ft of lines on a small spool. Pull out about 25ft of lines and put the spool in your pocket. This way you can walk around an fly!

See the Plutz videos in Youtube!